




## Call Settings

### Directory


1、	Skype for business.....	1
2、	Zoom Settings.....	3
3、	Skype Settings.....	5

# 1、 Skype for business


Step1: Click the settings icon;



Step 2: Select the "Audio Device" option, set the microphone and speaker to "HD Webcam eMeet C980 Pro" and click "OK".




Step 3: Select the "Video Device" option, set the video to "HD Webcam eMeet C980 Pro" and click "OK".




## 2、 Zoom Settings


Step1. Click the settings icon;




Step2: Select the "Video" setting and set the video to "HD Webcam eMeet C980 Pro";



Step3: Select the "Audio" setting and set the Speaker to "HD Webcam eMeet C980 Pro";




Step4: Select the Microphone of the " HD Webcam eMeet C980 Pro " device;




### 3、Skype Settings


Step 1: Click on the icon,select the "Settings" option ;



Step 2: Select the "Audio&Video" option and set the video to “HD Webcam eMeet C980 Pro” ;



Step 3: Set the microphone option to "HD Webcam eMeet C980 Pro";



Step 4: Set the speaker option to "HD Webcam eMeet C980 Pro";

